



Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

Revision 1/03.2013

Copyright © 2012-2013 Pavel Haiduc and HP InfoTech S.R.L. All rights reserved.

No part of this document may be reproduced in any form except by written permission of the author.

All rights of translation reserved.

Table of Contents

1. Introduction.....	3
2. Preparation.....	3
3. Creating a New Project	4
4. Editing the Source Code	16
5. Configuring the Project.....	17
6. Building the Project and Programming the Chip	19
7. Debugging the Program	20
8. Conclusion.....	25
Appendix A – The Source Code.....	26

1. Introduction

The purpose of this document is to guide the user through the preparation, building and debugging of an example C program using the CodeVisionAVR V3.03 or later C compiler extension for Atmel Studio 6.1 or later.

The example is a simple program for the Atmel ATmega328 microcontroller on an Arduino UNO board.

2. Preparation

Download and install Atmel Studio from www.atmel.com

Install the CodeVisionAVR C Compiler by executing the *CodeVisionAVR.msi* installer.

When prompted, use the default installation directory suggested by the installer.

Please note that Administrator privileges are required under Windows for installing and using CodeVisionAVR.

Make the following hardware preparations:


- If it is not already installed, solder a 6 pin header to the location marked ICSP on the Arduino UNO board
- Connect the cathodes of 8 LEDs to the outputs marked DIGITAL 0..7 on the board. These outputs correspond to PORTD pins PD0..PD7 of the microcontroller.
- Connect each LED's anode, using a 1k resistor, to the pin marked 5V of the board's POWER connector header.
- Connect the AVRISP MkII programmer to an USB port of your computer
- Connect the AVRISP MkII programmer to the ICSP header. Please check the correct orientation of the programmer's cable connector with the board's ICSP header pin 1.
- Connect the USB connector of the Arduino board to another USB port of your computer. This will provide power supply to the board.

3. Creating a New Project

Launch the Atmel Studio IDE.


Execute the **File|New|Project Using the CodeWizardAVR...** menu command.

A dialog window will be displayed, allowing selecting the AVR chip family for which the CodeWizardAVR will create the program:



Select the **AT90, ATtiny, ATmega** option and click on the OK button.

The CodeWizardAVR will be launched and the following window will be displayed:




In the **Chip Settings** panel, select the **Chip** type: ATmega328P and **Clock** frequency: 16 MHz.

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1


The next step is to configure the PORTD pins PD0 to PD7 as outputs.

In order to achieve this, click on the **Ports** node of the CodeWizard's tree.

A new configuration panel for **Port Settings** will be displayed:




Click on the **Port D** tab in order to select the PORTD configuration:



As can be seen, the Port D **Data Direction** for all I/O pins is set by default as inputs (**In**).

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

Click on each **Bit 0** to **Bit 7** button in order to set the I/O pins as outputs:




Ports Settings

Port B Port C Port D

Data Direction	Pullup/Output Value
Bit 0 Out	0 Bit 0
Bit 1 Out	0 Bit 1
Bit 2 Out	0 Bit 2
Bit 3 Out	0 Bit 3
Bit 4 Out	0 Bit 4
Bit 5 Out	0 Bit 5
Bit 6 Out	0 Bit 6
Bit 7 Out	0 Bit 7

As the LEDs must be OFF after chip reset, the potential of their cathodes must be +5V, so the **Output Values** for Port D **Bit 0** to **Bit 7** must be set to 1 by clicking on the corresponding buttons:



Ports Settings

Port B Port C Port D


Data Direction	Pullup/Output Value
Bit 0 Out	1 Bit 0
Bit 1 Out	1 Bit 1
Bit 2 Out	1 Bit 2
Bit 3 Out	1 Bit 3
Bit 4 Out	1 Bit 4
Bit 5 Out	1 Bit 5
Bit 6 Out	1 Bit 6
Bit 7 Out	1 Bit 7

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

The next step is to configure a Timer/Counter to generate an interrupt after each 200 ms.

Click on the  **Timers/Counters** node of the CodeWizard's tree.

A **Timers/Counters Settings** panel will be displayed:



Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

Timer1 will be used, so click on the corresponding tab:

The screenshot shows the 'Timers/Counters Settings' dialog box. The 'Requirements' tab is active, showing a 'Period' of 0.000000 ms with an up/down arrow icon. An 'Apply' button is at the bottom right. Below this, there are four tabs: 'Timer0', 'Timer1', 'Timer2', and 'Watchdog'. The 'Timer1' tab is selected. The settings for Timer1 are as follows:

- Clock Source: System Clock (dropdown)
- Clock Value: Timer1 Stopped (dropdown)
- Mode: Normal top=0xFFFF (dropdown)
- Out. A: Disconnected (dropdown)
- Out. B: Disconnected (dropdown)

Input Capture section:

- ☐ Noise Cancel
- ☐ Rising Edge

Interrupt on:

- ☐ Timer1 Overflow (dropdown)
- ☐ Input Capture (dropdown)

Value: 0 h Inp. Capture: 0 h

Comp. A: 0 h B: 0 h

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

As we need a Timer 1 compare match interrupt after each 200 ms, we must select the operating **Mode** as: **CTC top=OCR1A**, specify the **Period** value: *200 ms* in the **Requirements** panel and check the **Interrupt on Compare A Match** check box:

Timers/Counters Settings

Requirements

Period: 200.000000 ms

Apply

Timer0 Timer1 Timer2 Watchdog

Clock Source: System Clock

Clock Value: Timer1 Stopped

Mode: CTC top=OCR1A

Out. A: Disconnected

Out. B: Disconnected

Input Capture:

☐ Noise Cancel

☐ Rising Edge

Interrupt on:

☐ Input Capture

☒ Compare A Match

Value: 0 h Inp. Capture: 0 h

Comp. A: 0 h B: 0 h

In this operating mode the Timer 1 will count pre-scaled system clock pulses until the TCNT1 register will be equal with the value of the OCR1A register. When this will occur, the TCNT1 register will be automatically reset to 0 and a Timer 1 compare with OCR1A match interrupt will be generated.


Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1


By clicking on the **Apply** button in the **Requirements** panel, the CodeWizardAVR will establish the required values for Timer 1 configuration registers:

The screenshot shows the 'Timers/Counters Settings' dialog box with the 'Requirements' tab selected for 'Timer1'. The 'Period' is set to 200.000000 ms. Below this, it shows 'Obtained Period: 0.2 s' and '0.00 % error'. An 'Apply' button is visible. The 'Timer1' tab is active, showing 'Clock Source' as 'System Clock', 'Clock Value' as '250.000 kHz', 'Mode' as 'CTC top=OCR1A', 'Out. A' as 'Disconnected', and 'Out. B' as 'Disconnected'. Under 'Input Capture', 'Noise Cancel' and 'Rising Edge' are unchecked. Under 'Interrupt on:', 'Input Capture' is unchecked and 'Compare A Match' is checked. At the bottom, 'Value' is 0 h, 'Inp. Capture' is 0 h, 'Comp. A' is C34F h, and 'B' is 0 h.

As can be seen in the above window, the 16 MHz system clock will be divided by 64 in order to obtain a Timer 1 **Clock Value** of 250 kHz and the OCR1A register will be initialized with the value `0xC34F`. The obtained time period between two interrupts will be 0.2 seconds, matching our requirement with a 0% error.


Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

The next step, before generating the actual program code, is to specify some comments regarding our program by clicking on the  **Project Information** node and completing the comments in the corresponding panel:



Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

Using the **Program|Generate** menu or clicking on the  toolbar button, will create the C program, which can be previewed in the **Program Preview** window:




```
1  #include <mega328p.h>
2
3  // Declare your global variables here
4
5  // Timer1 output compare A interrupt service routine
6  interrupt [TIM1_COMPA] void timer1_compa_isr(void)
7  {
8      // Place your code here
9      |
10 }
11
12 void main(void)
13 {
14     // Declare your local variables here
15
16     // Crystal Oscillator division factor: 1
17     #pragma optimize-
18     CLKPR=(1<<CLKPCE);
19     CLKPR=(0<<CLKPCE) | (0<<CLKPS3) | (0<<CLKPS2) | (0<<CLKPS1) | (0<<CLKPS0);
20     #ifdef _OPTIMIZE_SIZE_
21     #pragma optimize+
22     #endif
23
24     // Input/Output Ports initialization
25     // Port B initialization
26     // Function: Bit7=In Bit6=In Bit5=In Bit4=In Bit3=In Bit2=In Bit1=In Bit0=In
27     DDRB=(0<<DDB7) | (0<<DDB6) | (0<<DDB5) | (0<<DDB4) | (0<<DDB3) | (0<<DDB2) | (0<<DDB1) | (
28     // State: Bit7=T Bit6=T Bit5=T Bit4=T Bit3=T Bit2=T Bit1=T Bit0=T
29     PORTB=(0<<PORTB7) | (0<<PORTB6) | (0<<PORTB5) | (0<<PORTB4) | (0<<PORTB3) | (0<<PORTB2) |
30
31     // Port C initialization
32     // Function: Bit6=In Bit5=In Bit4=In Bit3=In Bit2=In Bit1=In Bit0=In
33     DDRC=(0<<DDC6) | (0<<DDC5) | (0<<DDC4) | (0<<DDC3) | (0<<DDC2) | (0<<DDC1) | (0<<DDC0);
34     // State: Bit6=T Bit5=T Bit4=T Bit3=T Bit2=T Bit1=T Bit0=T
35     PORTC=(0<<PORTC6) | (0<<PORTC5) | (0<<PORTC4) | (0<<PORTC3) | (0<<PORTC2) | (0<<PORTC1) |
```

By clicking on a peripheral node in the CodeWizard's tree, the cursor in the **Program Preview** window will be positioned at the corresponding initialization code sequence for that peripheral.


Note: By default the CodeWizardAVR generates initialization code even for peripherals that are not in use (disabled).

This is a safety measure to configure correctly the chip if a software reset occurred by jumping to address 0. In order to reduce generated program size, this can be disabled by un-checking the **Program|Generate Code for Disabled Peripherals** menu option.


Once we are satisfied with the generated code, we must save the new program by using the **Program|Generate, Save and Exit** menu or clicking on  the toolbar button.

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

First we will be prompted for the name of the first .c source file of the project:




Next we will have to specify the name of the Atmel Studio project:




Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

And finally we must save the peripheral configuration for our project in a CodeWizardAVR project **.cwp** file:




This will allow us to use the same peripheral configuration for other projects, just by reloading the **.cwp** file in the CodeWizardAVR.

Once all these files were saved, Atmel Studio will prompt us if we wish to create a new solution for the "led demo" project:




Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

We will click on the **Yes** button and will be prompted for the solution name:



Once this is done, the new solution and project are loaded in Atmel Studio and the corresponding information is displayed in the Solution Explorer:




4. Editing the Source Code

The CodeWizardAVR has created all the code needed to initialize the peripherals for our application, now we must add the part of code required to execute our task: light sequentially with a 200 ms delay, each of the 8 LEDs connected to PORTD.

In order to open the project's C source file in the editor, we must double click on the **led demo.c** node in the Solution Explorer.

Once the file is loaded in the Editor window we can apply changes to it:



All the action of the program is performed by Timer 1 compare with OCR1A match interrupt service routine **timer1_compa_isr** which is called every 200 ms.

The required code will be added there, in bold text:

```
// Timer1 output compare A interrupt service routine
interrupt [TIM1_COMPA] void timer1_compa_isr(void)
{
// Place your code here


// If all LEDs are off, light the first one
if (PORTD == 0xFF) PORTD = 0xFE;
// One of the LEDs is already lighted, turn it off and light the next one
else PORTD = (PORTD << 1) | 1;
}
```

Note: As the LEDs' anodes are connected to +5V by a resistor and the cathodes are connected to PORTD outputs, in order for them to be lighted the corresponding output must be set to logic level 0.

5. Configuring the Project

Once the required changes were made to the program's source code, the next step is to configure the project's build options using the **Project|Configure** menu.


The dialog window will be displayed:



We need to automatically program the chip after a successful **Build**.

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

This can be achieved by selecting the **After Build** tab and enabling the **Program the Chip** option:




The following options must be set:

- **Programmer:** AVRISP MKII
- **SCK Freq:** 125000 Hz
- **Program Fuse Bit(s):** enabled
- All fuse bits **=0** not programmed state (not checked), except **BODLEVEL1=0** which must be in programmed state (checked).

The project configuration changes must be confirmed by clicking on the **OK** button.

6. Building the Project and Programming the Chip

The final step is compiling and linking our program using the **Build|Build led demo** menu command. After a successful build the following **Information** window will be displayed:



Clicking on the **Program the chip** button will transfer the compiled program to the chip's FLASH and program the fuse bits.

Once these operations are performed, the program will start executing.

7. Debugging the Program


Once the program was successfully built, it can be debugged in source level form using the Atmel Studio's **Simulator**.

A debugging session can be started using the **Debug|Start Debugging and Break** menu command, the  toolbar button or by pressing the **Alt+F5** keys.

If the source files were modified since the last **Build**, a **Rebuild** will be automatically performed, before the debugging will be started.

Atmel Studio uses the **.cof** object file produced by CodeVisionAVR for debugging.


When the debugging session will be started for the first time, the user will be prompted to select the tool that will be using for tracing the program execution:



For our example, we will select the **Simulator** and click on the **OK** button.

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

After the debugging tool was selected, the debugging session actually starts:




The simulator first executes the low level startup initialization code, which consists of filling all RAM locations with 0s, initializing the global variables, data and hardware stack pointers.

Once these operations are finished, the program execution is passed to the **main** function of the program.

The debugger stops the program execution at the first C source line of **main**, allowing the user to single-step the program from there.

The AVR chip registers are displayed in the **Processor** window.

By default the simulator uses a clock frequency of 1.000MHz, but in our example the chip is clocked at 16.000MHz, so this must be modified by clicking on the **Frequency** field and entering the correct value there:




and pressing **Enter**.

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

The next step in debugging our program is to set a breakpoint at the beginning of the Timer 1 output compare A interrupt service routine **timer1_compa_isr**.

This is achieved by placing the cursor on the first line of code in the above mentioned function and selecting the **Debug|Toggle Breakpoint** menu command or pressing the **F9** key:



The screenshot shows the CodeVisionAVR IDE with a file named 'led demo.c' open. The 'timer1_compa_isr' function is selected in the left-hand pane. The main editor window displays the source code for this function and the 'main' function. A red circle, representing a breakpoint, is placed on the first line of the 'timer1_compa_isr' function: 'interrupt [TIM1_COMPA] void timer1_compa_isr(void)'. The line is highlighted in blue. The code includes comments and logic for controlling LEDs via PORTD. The 'main' function is also visible, showing variable declarations and initialization of the clock prescaler (CLKPR).

```
#include <mega328p.h>

// Declare your global variables here


// Timer1 output compare A interrupt service routine
interrupt [TIM1_COMPA] void timer1_compa_isr(void)
{
    // Place your code here


    // If all LEDs are off, light the first one
    if (PORTD == 0xFF) PORTD = 0xFE;
    // One of the LEDs is already lighted, turn it off and light the next one
    else PORTD = (PORTD << 1) | 1;
}

void main(void)
{
    // Declare your local variables here

    // Crystal Oscillator division factor: 1
    #pragma optsize-
    CLKPR=(1<<CLKPCE);
    CLKPR=(0<<CLKPCE) | (0<<CLKPS3) | (0<<CLKPS2) | (0<<CLKPS1) | (0<<CLKPS0);
    #ifdef _OPTIMIZE_SIZE_
    #pragma optsize+
    #endif
}
```

The line with the breakpoint will be highlighted.


After the breakpoint was set, we can continue single stepping through our program using **Debug|Step Into** menu command, the **F11** key or the  toolbar button.

We can start executing our program, until the breakpoint is reached, by selecting the **Debug|Continue** menu command, pressing the **F5** key or the  toolbar button.

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

Important Note: The Atmel Studio **Simulator** executes the program at a much lower speed than the real AVR chip, so reaching the breakpoint set in the **timer1_compa_isr** function doesn't occur in real time after 200 ms.

Depending on the host PC speed the simulator will appear to hang for 1...2 minutes, but finally the program execution stops at the breakpoint:



```
led demo.c x
timer1_compa_isr
External RAM size : 0
Data Stack size : 512
*****/

#include <mega328p.h>

// Declare your global variables here


// Timer1 output compare A interrupt service routine
interrupt [TIM1_COMPA] void timer1_compa_isr(void)
{
    // Place your code here

    // If all LEDs are off, light the first one
    if (PORTD == 0xFF) PORTD = 0xFE;
    // One of the LEDs is already lighted, turn it off and light the next one
    else PORTD = (PORTD << 1) | 1;
}

void main(void)
{
    // Declare your local variables here

    // Crystal Oscillator division factor: 1
    #pragma optimize-
    CLKPR=(1<<CLKPCE);
    CLKPR=(0<<CLKPCE) | (0<<CLKPS3) | (0<<CLKPS2) | (0<<CLKPS1) | (0<<CLKPS0);
    #ifdef _OPTIMIZE_SIZE_
    #pragma optimize-
```

As the program execution stopped inside the **timer1_compa_isr** function, we will note the **Stop Watch** value of **200776.44 µs** in the **Processor** window:



Name	Value
Program Counter	0x0000005D
Stack Pointer	0x08FD
X Register	0x0900
Y Register	0x02FE
Z Register	0x1802
Status Register	I T H S V N Z C
Cycle Counter	3212423
Frequency	16.000 MHz
Stop Watch	200,776.44 µs

This value is slightly larger than the 200 ms which we have specified as the Timer 1 output compare interrupt period.


The additional 776.44 µs are required by the startup initialization code, after chip reset and the moment the Timer 1 registers are first initialized and counting is started.

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

We will press the **F5** key again to continue program execution.

The simulator will stop again at the breakpoint in **timer1_compa_isr** after 1...2 minutes, depending on the host PC speed.

This time the **Stop Watch** value in the **Processor** window will be **400776.38 µs**:










Name	Value
Program Counter	0x0000005D
Stack Pointer	0x08FD
X Register	0x0900
Y Register	0x02FE
Z Register	0x1802
Status Register	I T H S V N Z C
Cycle Counter	6412422
Frequency	16.000 MHz
Stop Watch	400,776.38 µs

So the time interval between two Timer 1 output compare A interrupts will be:

$$400776.38 \mu\text{s} - 200776.44 \mu\text{s} = 199999.94 \mu\text{s} = 199.99994 \text{ ms}$$

which is equal to the required 200 ms with a negligible error.

The following additional commands can be used when debugging:

- **Debug|Step Over**, F10 key or  toolbar button to execute one instruction. If the instruction contains a function call, the function is executed as well.
- **Debug|Step Out**, Shift+F11 keys or  toolbar button to continue execution until the current function has completed
- **Debug|Run To Cursor**, Ctrl+F10 keys or  toolbar button to continue execution until the current cursor position in the source file or disassembly view is reached
- **Debug|Reset**, Shift+F5 keys or  toolbar button to restart program execution from the beginning
- **Debug|Restart** or  toolbar button to restart the debugger and reload the debugged program
- **Debug|Toggle Breakpoint** or F9 key to set a breakpoint at the current cursor position in the C source file or disassembly view
- **Debug|New Breakpoint|Break at Function** to set a breakpoint at the beginning of a particular function
- **Debug|Delete All Breakpoints** or Ctrl+Shift+F9 keys to delete all the breakpoints that were set
- **Debug|Disable All Breakpoints** to temporarily disable all the breakpoints that were set
- **Debug|Enable All Breakpoints** to re-enable all the breakpoints that were set
- **Debug|Break All**, Ctrl+F5 keys or  toolbar button to stop program execution
- **Debug|Windows** allow displaying specific windows for watching variables, processor registers, I/O and peripheral registers, memory contents, code disassembly, etc.
- **Debug|Stop Debugging**, Ctrl+Shift+F5 keys or  toolbar button stops the debugging session.

To obtain more information about using the debugger, please consult the Atmel Studio Help.

Note: The compiler applies some optimization techniques that may prevent correct debugging of the executable program.

Therefore it is recommended to select the **Project|Configure|C Compiler|Code generation|Optimize for: Speed** option for code debugging.

If the program fits in the chip's FLASH, this option must be left enabled for **Release** too, as the program will execute faster this way.

8. Conclusion

This document provides the necessary starting guidelines for rapid development and debugging of an application using the CodeVisionAVR extension for Atmel Studio.

CodeVisionAVR is supplied with a comprehensive Help and User Manual, which must be extensively studied in order to take full advantage of all the features of the C compiler, associated peripheral libraries, CodeWizardAVR and LCD Vision font/image editor/converter for graphic displays.

The compiler is supplied with a large number of example programs covering:

- Alphanumeric LCD
- Graphic LCD, TFT and OLED displays
- SD Memory Cards
- USART
- TWI, I²C
- SPI
- ADC
- Boot loaders
- USB
- Web Server
- XMEGA EBI
- XMEGA Quadrature Encoder
- XMEGA DAC
- DS1820, DS18B20, LM75, DS1621 temperature sensors

These programs are located in the **\Examples** and **\Examples ATxmega** subdirectories of the CodeVisionAVR installation directory.

Appendix A – The Source Code

```
/******  
This program was created by the  
CodeWizardAVR V3.03 Standard  
Automatic Program Generator  
© Copyright 1998-2013 Pavel Haiduc, HP InfoTech s.r.l.  
http://www.hpinfotech.com  
  
Project : Moving LED demo  
Version : 1.0  
Date    : 14/03/2013  
Author  : Pavel Haiduc  
Company : HP InfoTech  
Comments:  
This is a simple program  
  
Chip type           : ATmega328P  
Program type        : Application  
AVR Core Clock frequency: 16.000000 MHz  
Memory model        : Small  
External RAM size    : 0  
Data Stack size     : 512  
*****/  
  
#include <mega328p.h>  
  
// Declare your global variables here  
  
// Timer1 output compare A interrupt service routine  
interrupt [TIM1_COMPA] void timer1_compa_isr(void)  
{  
    // Place your code here  
  
    // If all LEDs are off, light the first one  
    if (PORTD == 0xFF) PORTD = 0xFE;  
    // One of the LEDs is already lighted, turn it off and light the next one  
    else PORTD = (PORTD << 1) | 1;  
}  
  
void main(void)  
{  
    // Declare your local variables here  
  
    // Crystal Oscillator division factor: 1  
    #pragma optsize-  
    CLKPR=(1<<CLKPCE);  
    CLKPR=(0<<CLKPCE) | (0<<CLKPS3) | (0<<CLKPS2) | (0<<CLKPS1) | (0<<CLKPS0);  
    #ifdef _OPTIMIZE_SIZE_  
    #pragma optsize+  
    #endif
```

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

```
// Input/Output Ports initialization
// Port B initialization
// Function: Bit7=In Bit6=In Bit5=In Bit4=In Bit3=In Bit2=In Bit1=In Bit0=In
DDRB=(0<<DDB7) | (0<<DDB6) | (0<<DDB5) | (0<<DDB4) | (0<<DDB3) | (0<<DDB2) | (0<<DDB1) |
      (0<<DDB0);
// State: Bit7=T Bit6=T Bit5=T Bit4=T Bit3=T Bit2=T Bit1=T Bit0=T
PORTB=(0<<PORTB7) | (0<<PORTB6) | (0<<PORTB5) | (0<<PORTB4) | (0<<PORTB3) | (0<<PORTB2) |
      (0<<PORTB1) | (0<<PORTB0);

// Port C initialization
// Function: Bit6=In Bit5=In Bit4=In Bit3=In Bit2=In Bit1=In Bit0=In
DDRC=(0<<DDC6) | (0<<DDC5) | (0<<DDC4) | (0<<DDC3) | (0<<DDC2) | (0<<DDC1) | (0<<DDC0);
// State: Bit6=T Bit5=T Bit4=T Bit3=T Bit2=T Bit1=T Bit0=T
PORTC=(0<<PORTC6) | (0<<PORTC5) | (0<<PORTC4) | (0<<PORTC3) | (0<<PORTC2) | (0<<PORTC1) |
      (0<<PORTC0);

// Port D initialization
// Function: Bit7=Out Bit6=Out Bit5=Out Bit4=Out Bit3=Out Bit2=Out Bit1=Out Bit0=Out
DDRD=(1<<DDD7) | (1<<DDD6) | (1<<DDD5) | (1<<DDD4) | (1<<DDD3) | (1<<DDD2) | (1<<DDD1) |
      (1<<DDD0);
// State: Bit7=1 Bit6=1 Bit5=1 Bit4=1 Bit3=1 Bit2=1 Bit1=1 Bit0=1
PORTD=(1<<PORTD7) | (1<<PORTD6) | (1<<PORTD5) | (1<<PORTD4) | (1<<PORTD3) | (1<<PORTD2) |
      (1<<PORTD1) | (1<<PORTD0);

// Timer/Counter 0 initialization
// Clock source: System Clock
// Clock value: Timer 0 Stopped
// Mode: Normal top=0xFF
// OC0A output: Disconnected
// OC0B output: Disconnected
TCCR0A=(0<<COM0A1) | (0<<COM0A0) | (0<<COM0B1) | (0<<COM0B0) | (0<<WGM01) | (0<<WGM00);
TCCR0B=(0<<WGM02) | (0<<CS02) | (0<<CS01) | (0<<CS00);
TCNT0=0x00;
OCR0A=0x00;
OCR0B=0x00;

// Timer/Counter 1 initialization
// Clock source: System Clock
// Clock value: 250.000 kHz
// Mode: CTC top=OCR1A
// OC1A output: Disconnected
// OC1B output: Disconnected
// Noise Canceler: Off
// Input Capture on Falling Edge
// Timer Period: 0.2 s
// Timer1 Overflow Interrupt: Off
// Input Capture Interrupt: Off
// Compare A Match Interrupt: On
// Compare B Match Interrupt: Off
TCCR1A=(0<<COM1A1) | (0<<COM1A0) | (0<<COM1B1) | (0<<COM1B0) | (0<<WGM11) | (0<<WGM10);
TCCR1B=(0<<ICNC1) | (0<<ICES1) | (0<<WGM13) | (1<<WGM12) | (0<<CS12) | (1<<CS11) |
      (1<<CS10);
TCNT1H=0x00;
TCNT1L=0x00;
ICR1H=0x00;
ICR1L=0x00;
OCR1AH=0xC3;
OCR1AL=0x4F;
```

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

```
OCR1BH=0x00;
OCR1BL=0x00;

// Timer/Counter 2 initialization
// Clock source: System Clock
// Clock value: Timer2 Stopped
// Mode: Normal top=0xFF
// OC2A output: Disconnected
// OC2B output: Disconnected
ASSR=(0<<EXCLK) | (0<<AS2);
TCCR2A=(0<<COM2A1) | (0<<COM2A0) | (0<<COM2B1) | (0<<COM2B0) | (0<<WGM21) | (0<<WGM20);
TCCR2B=(0<<WGM22) | (0<<CS22) | (0<<CS21) | (0<<CS20);
TCNT2=0x00;
OCR2A=0x01;
OCR2B=0x00;

// Timer/Counter 0 Interrupt(s) initialization
TIMSK0=(0<<OCIE0B) | (0<<OCIE0A) | (0<<TOIE0);

// Timer/Counter 1 Interrupt(s) initialization
TIMSK1=(0<<ICIE1) | (0<<OCIE1B) | (1<<OCIE1A) | (0<<TOIE1);

// Timer/Counter 2 Interrupt(s) initialization
TIMSK2=(0<<OCIE2B) | (0<<OCIE2A) | (0<<TOIE2);

// External Interrupt(s) initialization
// INT0: Off
// INT1: Off
// Interrupt on any change on pins PCINT0-7: Off
// Interrupt on any change on pins PCINT8-14: Off
// Interrupt on any change on pins PCINT16-23: Off
EICRA=(0<<ISC11) | (0<<ISC10) | (0<<ISC01) | (0<<ISC00);
EIMSK=(0<<INT1) | (0<<INT0);
PCICR=(0<<PCIE2) | (0<<PCIE1) | (0<<PCIE0);

// USART initialization
// USART disabled
UCSR0B=(0<<RXCIEN0) | (0<<TXCIEN0) | (0<<UDRIEN0) | (0<<RXEN0) | (0<<TXEN0) | (0<<UCSZ02) |
        (0<<RXB80) | (0<<TXB80);

// Analog Comparator initialization
// Analog Comparator: Off
// The Analog Comparator's positive input is
// connected to the AIN0 pin
// The Analog Comparator's negative input is
// connected to the AIN1 pin
ACSR=(1<<ACD) | (0<<ACBG) | (0<<ACO) | (0<<ACI) | (0<<ACIE) | (0<<ACIC) | (0<<ACIS1) |
        (0<<ACIS0);
ADCSRB=(0<<ACME);
// Digital input buffer on AIN0: On
// Digital input buffer on AIN1: On
DIDR1=(0<<AIN0D) | (0<<AIN1D);

// ADC initialization
// ADC disabled
ADCSRA=(0<<ADEN) | (0<<ADSC) | (0<<ADIF) | (0<<ADIE) | (0<<ADPS2) |
        (0<<ADPS1) | (0<<ADPS0);
```

Getting Started with the CodeVisionAVR Extension for Atmel Studio 6.1

```
// SPI initialization
// SPI disabled
SPCR=(0<<SPIE) | (0<<SPE) | (0<<DORD) | (0<<MSTR) | (0<<CPOL) | (0<<CPHA) | (0<<SPR1) |
      (0<<SPR0);

// TWI initialization
// TWI disabled
TWCR=(0<<TWEA) | (0<<TWSTA) | (0<<TWSTO) | (0<<TWEN) | (0<<TWIE);

// Global enable interrupts
#asm("sei")

while (1)
{
    // Place your code here

}
}
```